



Connection Functions

At Terminal	Function
D/U D	Speech from door
D/U C	Speech unit supply
D/U E	Speech to door
PSU 12	12v AC for ringing & lock
PSU 0	12v AC for ringing & lock
PSU +	12v DC for speech & lamps
PSU -	12v DC for speech & lamps
TEL A2	Ringer Warble
TEL A1	Ringer buzzer (if fitted)
TEL L	Speech from door
TEL P	Speech to door
TEL 1	Lock button
TEL B	Common for ringers
TEL F	Common for speech
TEL G	Common for buttons

Plan 1 Provides Ringing, Communication and Door Release functions.

Notes Insert LINKS everywhere shown ●●. Ringer Warble volume, all phones have a spindle at the top left corner. Speech volume is adjustable on the back of the entrance panel. Speaker and Microphone have separate controls.

Title : WDA_1S_3_201_92

Date : August 2017 Drawn by : TH